

OUR DATE 2018-02-06
DEPARTMENT Global RD, AD&T
FROM Anette Johansson

REG NO TL-5630/18

EDITION

REPLACEMENT PROJECT NO

PAGE 1 (21)

SUBJECT Washing performance test of ultra-pure water at MKB ,Malmö.

то

CC

1. Background /Introduction

A new alternative washing process has been installed in a house property in Malmö.

The new process washes without detergent, with cold or hot water, as good as with detergent, according to the company Swatab.

Swatab also said that the load will dry quicker, depending on lower residual moisture after extraction, 20% less, with ultra-pure water. The explanation was that detergent will attach or hold water and without detergent the residual moisture will be lower after extraction.

This is a performance test of this new process, from Swatab, with ultra-pure water at MKB in Malmö.

The purpose was to verify the washing performance and also the residual moisture after extraction.

The machines used, were Electrolux W575HLE.

Two different cold programs with ultra-pure water were tested.

Duration for program 1 was around 28 minutes and for program 2, around 35 minutes.

Local reference tests were done with water only, liquid detergent and IEC detergent. The tested program was "Normal 60 color" (N60 color), this program lasted for 48-50 minutes.

Washing performance and residual water were evaluated.

2. Summary of results / Conclusion

The best washing performance was achieved with liquid detergent (N60 color) and IEC detergent.

The liquid detergent (N60 color) was best on sebum, soot and blood.

The IEC detergent was best on chocolate and wine.

Water was better than the ultra-pure water, both programs, on all five soils.

The ratio, q (the average sum of reflectance of the test process and the standard reference machine (Electrolux FOM71CLS.)) was 0.95 for the both processes with liquid detergent and IEC detergent. This is class D.

Water, achieved q=0.76, class J and ultra-pure water, 0.69 and 0.66, class N and M.



A q-value higher than 0.85 considered as a good washing result according to my experience and also to the old Swedish board of consumers. (They had a five degrees scale in washing performance, where q=0.85 means degree 3.)Today this mean class G according to the scale of CENELEC (European Committee for Electrotechnical Standardization)

Water, q=0.76, was 3-4 classes better than ultra-pure water. (In CENELEC a range of q=0.03 is one class.)

The conclusion of this test is that detergent is required to obtain better washing performance than q=0.85, class G.

Best washing performance shows the liquid detergent (N60color) and the IEC detergent The two processes with ultra-pure water show lower washing performance, than wate onlyr shows in the N60 program.

The test shows that the residual moisture is quite the same for all processes. The lowest residual moisture evaluated with liquid detergent + softener (47.6%). The highest with only water (51.6%). My explanation why the process with softener gives a lower residual moisture is that softener decrease the surface tension of water and then the textile releases more water.



Sammanfattning

En anläggning med ultra-rent vatten har testats på Malmö Kommunala Bostadsbolag i Malmö. Två maskiner Electrolux W575HLE testades med program 1 och 2.

Programmen tog 28 respektive 35 minuter.

I referensanläggningen testades två W575HLE med program N60 kulör.

Detta program tog ca 48-50 minuter.

Programmet testades med enbart vatten, flytande automatisk dosering och IEC tvättmedel.

Bäst sammanlagt tvättresultat erhöll flytande tvättmedel samt IEC tvättmedlet. Flytande tvättmedlet var bäst på smutserna, sebum, sot och blod. IEC tvättmedlet var bäst på choklad och vin. Vanligt vatten var bättre än ultra-rent vatten på samtliga fem smutser. Förhållandet, q, summan av reflektansen av den testade processen och standard referensen (FOM71CLS), var 0.95 för båda de bästa processerna med flytande och IEC tvättmedel, motsvarar klass D.

Vatten erhöll q=0.76, vilket motsvarar klass J och ultra-rent vatten processerna erhöll q=0.69 resp. q=0.66, motsvararande klass N och M.

Högre än 0.85 är ett godkänt tvättresultat, enligt min erfarenhet och även enligt den gamla skalan på Konsumentverket i Sverige. Konsumentverket hade en 5 gradig skala, där q=0.85 motsvarade tvättbetyg 3, som var godkänt. Idag motsvarar det klass G enligt CENELECs skala.

Vanligt vatten i N60 kulör var 3-4 klasser bättre än program 1 och 2 med ultra-rent vatten. I CENELEC motsvarar en klass 0.03 i reflektans.

Testet visar att tvättmedel behövs för att erhålla ett godkänt tvättresultat. De två processerna med ultra rent vatten visade sämre resultat än vanligt vatten i N60 kulör programmet.

Testerna visade att restfuktigheten skilde väldigt lite mellan de olika testerna, vilket kan förklaras av att det är samma slutcentrifugering i alla testerna.

Lägst restfuktighet erhöll testen med flytande tvättmedel och sköljmedel 47.6%.

Högst hade vanligt vatten med 51.6%. Testerna med ultrarent vatten erhöll 50%.

Min förklaring till detta är att sköljmedel sänker ytspänningen på vattnet och därmed släpper vattnet lättare från textilierna.



Contents

1. Background /Introduction	1
2. Summary of results / Conclusion]
Sammanfattning	3
3.Method	5
3.1 Washing process	5
3.2 Washing performance	6
3.3 Re soiling	7
3.4 Residual moisture	7
Result	8
Washing Performance	8
Table 1	9
Diagram 1	9
Diagram 2.	1(
Diagram 3.	10
Diagram 4.	11
Diagram 5	11
Re-soil	12
	12
Residual moisture	12
Table 2	12
Diagram 6	13
Discussion	13
Appendix	14
Program description	14
Program 1 Ultra-pure	14
Program 2 Ultra-pure)	17
Program Normal 60 Colour	21



3. Method

3.1 Washing process

3.1.1 Standard reference

Complete process according to standard IEC EN 60456.

Machine: FOM71 CLS Program: Cotton 60 Tap water: 4°dH

Detergent: IEC detergent Dosage: 74 g (soft water)

3.1.2.1. Local reference liquid detergent N60 color

Machines: W575HLE

Program: Normal 60 color (see description in appendix)

Duration around 48 min

Tap water: 7°dH

Detergent: Liquid Henkel Eco-Lab Dosage: Turbo emulsion future 6 ml/kg

Turbo oxysan 1 ml/kg

Softenit dual excellence 3 ml/kg

3.1.2.2. Local reference liquid detergent N60 white

Machines: W575HLE

Program: Normal 60 white (see description in appendix)

Duration around 48 min

Tap water: 7°dH

Detergent: Liquid Henkel Eco-Lab Dosage: Turbo emulsion future 7 ml/kg

Turbo oxysan 2.5 ml/kg

Softenit dual excellence 3 ml/kg

3.1.2.3. Local reference IEC detergent

Machines: W575HLE Program: Normal 60 color

Duration around 48 min

Tap water: 7°dH

Detergent: IEC according standard IEC EN 60456

Dosage: 34g+ 10g/kg (7°dH)

3.1.2.4. Local reference water

Machines: W575HLE

Program: Normal 60 color (see description in appendix)

Duration around 48 min

Tap water: 7°dH Detergent: No Dosage: No







3.1.3.1 Tested process with ultra-pure water Pr.1

Machines: W575HLE

Program: Program 1 (see description in appendix)

Cold program duration around 28 min

Tap water: *Ultra-pure water

Detergent: No Dosage: No

3.1.3.2 Tested process with ultra-pure water Pr.2

Machines: W575HLE

Program: Program 2 (see description in appendix)

Cold program duration around 35 min

Tap water: *Ultra-pure water

Detergent: No Dosage: No

*The water was purified in an equipment from Swatab. The equipment consists of a pre filter, reverse osmosis and ion exchangers. The water has a conductivity of 0.1-0.3 uS/cm, according to Swatab.

3.2 Washing performance

The washing tests were performed according to IEC60456 Ed5.

Minolta spectrophotometer CM-3610d, used for the reflectance measuring.

The load was 5 kg of standard cotton.

Test pieces from EMPA were used, serie 129.

Five test pieces were used in each wash.

The washing performance evaluated by measure the reflectance of the EMPA test pieces.

There are five different soils and one unsoiled, called white. The five soils are sebum, soot, blood, chocolate and wine.

The higher the reflectance on the test pieces (i.e. the whiter after washing), the better washing performance.

The sum and mean values of the reflectance for the five soils, are calculated for each process. The ratio, q is calculated as the average sum of reflectance of the tested process (Ctest) and for the standard reference (Cref). q=Ctest/Cref

CENELEC (European Committee for Electrotechnical Standardization) has defined a scale with classes from A-G, where A is best.

A difference of 0.03 in reflectance means one class in the scale.

Ratio, q, above 1.03 means an A.

A q-value higher than 0.85 considered as a good washing result according to my experience and also to the old Swedish boarder of consumers. (They had a five degrees scale in washing performance, where q=0.85 means degree 3.) Today this mean class G according to the scale of CENELEC.





3.3 Re soiling

Re soil means when the soils are solved in the water and then reattach to the textiles. There are not enough with force to keep the soil in solution.

The effect can be observed as greying after many washes or as here when the white ballast gets dirty.

3.4 Residual moisture

This means the water that was left in the textiles after extraction, divide with the dry load that was used.

The load was weighed bone-dry (which mean it was dried until no water was left in the textiles) and then it was calculated to dry weight. The standard cotton hold 8 % moisture at 20 °C and 65 %RH.

Four standard loads 1-4 were weighed for the testes.

All loads weighed after each test and the residual moisture was calculated for each test.



Result

Washing Performance

Best washing performance has the two processes, liquid detergent N60 color and IEC detergent, with a mean reflectance of 62.2 (See diagram 1). The two processes with Ultra-pure water cleaned worse, than water.

The diagram 1 shows the result for the mean value for all 5 stains, diagram 2 shows the blood stain and diagram 3 shows the wine stain.

Table 1 shows all reflectance values for all stains and processes.

Water cleaned better than ultra-pure water for all the five stains. Liquid detergent was best on sebum, soot and blood.

IEC detergent was best on chocolate and wine.


Best washing result shows the processes with liquid detergent color and IEC detergent 0.95, class D. Water, 0.76, class J and ultra-pure water, 0.69 and 0.66, class N and M.

Water only with a q=0.76, was 0.07-0.10 better than ultra-pure water Pr.1 and 2. In CENELEC 0.03 is one class. This will mean that water only was 3-4 classes better than the ultra-pure water.

Diagram 5 shows the line for the scale.

Figure 1. Shows the EMPA test pieces. Processes from the left.

Liquid detergent N60color (D1) and liquid detergent N60 white (D6), IEC detergent (I11), water (V1), ultra-pure water Pr.1 (U9) and ultra-pure water Pr.2 (U16).



White (unsoiled)

Sebum

Soot

Blood

Chocolate

Wine

Table 1Shows the reflectance for all soils.

Machine	q=Ctest/Cref	White	Sebun	Soot	Blood	Chocolate	Wine	Sum	х
Reference Cotton 60	1,0	88,7	71,0	47,3	74,6	64,6	70,3	327,8	65,6
Det liq.N60 color	0,95	87,1	71,3	50,0	71,4	56,2	62,1	310,9	62,2
Det liq. N60 White	0,85	85,4	66,2	37,8	69,3	49,9	56,9	280,1	56,0
IEC N60	0,95	87,7	68,1	45,0	66,5	59,1	72,1	310,8	62,2
Ultra pure Pr 1	0,66	87,6	58,2	31,3	27,9	42,4	56,8	216,6	43,3
Ultrapure Pr 2	0,69	88,4	59,4	33,8	28,6	44,4	59,3	225,6	45,1
Water N60	0,76	85,9	63,9	38,0	37,7	45,7	65,1	250,3	50,1

Diagram 1

Shows the Mean values for the five different soils. Liquid detergent N60 color and IEC detergent, with reflectance of 62.2, show best result. Water cleans better than both the two processes with ultra-pure water.




Diagram 2.

Shows the reflectance for the blood soil.

All the washes with detergent were much better than the processes without detergent. Water cleans better than both the two processes with ultra-pure water.




Diagram 3.

Shows the reflectance for the wine soil.

IEC detergent has the best bleaching effect on wine.

Ultra-pure water gave the lowest reflectance.

Noteworthy is that water is better than both the processes with liquid detergent.




Diagram 4.

Shows the ratio q (q=Ctest/Cref) for the different processes.

Best washing result shows the processes with liquid detergent color and IEC detergent 0.95, means class D, in the scale of CENELEC.

Water, q=0.76, class J and ultra-pure water Pr.2, q= 0.69 and Pr.1 q=0.66, class N and M.

A q-value higher than 0.85 considered as a good washing result.

Tap water, 0.76, was 0.07-0.10 better than ultra-pure water. In CENELEC 0.03 is one class.




Diagram 5


Shows the performance classes A-N in the scale of CENELEC.

Best washing result shows the processes with liquid detergent color and IEC detergent 0.95, means class D, in the scale of CENELEC.

Water, q=0.76, class J and ultra-pure water Pr.2, q= 0.69 and Pr.1 q=0.66, class N and M.

A q-value higher than 0.85 considered as a good washing result.

Tap water, 0.76, was 0.07-0.10 better than ultra-pure water. In CENELEC 0.03 is one class.





Re-soil

Figure 2. to the left shows the ballast from the process with detergent. The textiles is still white.

Figure 3. to the right shows the ballast from the process with ultra-pure water.

The stains have been solved in the water and then reattached to the textiles.

Detergent is needed to keep the soils in the water.





2. Shows clean ballast

3. Shows re-soiled ballast

Residual moisture

Four different cotton loads, 1-4, were used.

The residual moisture are quite the same in all tests. Lowest residual moisture was achieved with liquid detergent that also contained softener in last rinse. Detergent and softener decrease the surface tension of water and then the textiles released more water.


The tests with liquid detergent shows the least water retention, 47.6 %. The test with only water holds most water 51.6 %. See table 2 and diagram 6.

Table 2Shows the residual moisture for the different processes.

		Bone-	Dry	Wet	Water	
Program	Load	dry	weight	weight	retention	Mean x
		kg	kg	kg	%	%
Pr 1 Ultra-pure	4	4,58	4,95	7,51	51,7	
Pr 1 Ultra-pure	1	4,59	4,96	7,38	48,8	
Pr 2 Ultra-pure	4	4,58	4,95	7,43	50,1	
Pr 2 Ultra-pure	1	4,59	4,96	7,43	49,8	50,1
N60 Water	2	4,53	4,89	7,41	51,5	
	3	4,57	4,94	7,49	51,6	51,6
N60 Liquid Det.	3	4,57	4,94	7,37	49,2	
	2	4,53	4,89	7,14	46,0	47,6
N60 IEC	4	4,58	4,95	7,34	48,3	
	3	4,57	4,94	7,4	49,8	49,0

Diagram 6

Shows the residual moisture for the different processes.



Discussion

The conclusion of this test is that detergent is required to obtain better washing performance than q=0.85, class G.

Best washing performance shows the liquid detergent (N60color) and the IEC detergent.

The two processes with ultra-pure water show lower washing performance, than water only shows in the N60 program.

In the ultra-pure processes some of the stains have been solved and then re soiled the textiles. Detergent is needed to keep the soils in the water.

The lowest residual moisture achieved with liquid detergent, as also has softener added in last rinse. Detergent and softener decrease the surface tension of water and then the textiles released more water.

The process with liquid detergent N60 white seems to achieved too low values regarding washing performance. The dosage here is little higher both for detergent and bleach compared with N60 color. A possible reason is that the automatic dosing system did not provide the programmed doses of detergent during that run.



Appendix

Program description

Program 1 Ultra-pure

PROGRAM 1

Free text	NORMALTVÄTT	
Machine Modules	W575H 17	
	Huvuddata Buzzer at Program end Prowder, flush valve from wash program Program ootlon changes allowed Motor action 1 on time, CW Motor action 1 of time Motor action 1 of time Motor action 1 of time Motor action 2 on time, CW Motor action 2 on time, CW Motor action 3 on time, CW Motor action 3 on time, CW Motor action 3 on time. CW	On On On O0:06 O0:06 O0:15 O0:15 O0:04
	Motor action 3 on time, CCW Motor action 3 off time Hotor action 4 off time Motor action 5 off time	00:08 00:07 00:03 00:03
	Huvudtvätt(1) Reheat Module heated Wash Time (Min.Sec) Temperature Temperature temperature temperature Temperature temperature thystereses Max Temp. Increase per min First Fil Level (Set mm) Second Fill Level (Set mm) Second Fill Level (Set mm) Hotor Speed During Filling (Rom) Hotor Speed During Heating (Rom) Hotor Speed During Wash (Rom) Hotor acceleration (RPM/sec) during filling Hotor acceleration (RPM/sec) during heating Hotor acceleration (RPM/sec) during wash Detergark Compartment 4	On O
	Huvudtvätt(2) Reheat Hodule heated Wash Time (Min:Sec) Temperature	On On:30 O:C O*C 38°C 10 0 2 2 2 2 2 30 49 49 25 25 25 00:10
3	Huvudtvätt(3) Wash Time (Hin:Sec) Temperature Temperature Hystereses Hax Temp, Increase per min First Fill Level (Set mm) Second Fill Level (Set mm)	02:30 0°C 4°C 33°C 61 70
	Level Hystereses (Scale Units) Motor action fill Motor action heat Motor action wash Motor Seed During Filling (Rpm)	10 2 2 2 30
	Motor Speed During Healting (Rpm) Hotor Speed During Healting (Rpm) Hotor Speed During Wash (Rpm) Hotor acceleration (RPM-Sec) during filling Hotor acceleration (RPM-Sec) during healting Hotor acceleration (RPM-Sec) during wash Detergent Compartment 5	49 49 25 25 25 Level refill

W575H



4	Huvudtvätt(4)	-
	Module heated	On 01:00
	Wash Time (Min:Sec)	0°C
	Temperature	4°C
	Temperature Hystereses Max Temp. Increase per min	38°C
	Second Fill Level (Set mm)	73
	Level Hystereses (Scale Units)	21
	Motor action fill	2
	Motor action heat	2
	Hotor action wash	2
	Motor Speed During Filling (Rpm)	30 49
	Motor Speed During Heating (Rpm)	49
	Motor Speed During Wash (Rpm)	25
	Motor acceleration (RPM/sec) during filling	25
	Motor acceleration (RPM/sec) during heating Motor acceleration (RPM/sec) during wash	25
	Detergent Compartment 5	Level refill
5	Avlopp(1)	
9	Drain Normal	On
	Hotor Action	2
	Drain Time (min:sec)	00:10
	Distribution Time (min:sec)	00:01
	Motor Speed During Drain Time (Rpm)	49
	Motor Acceleration During Drain (Rpm/sec)	25
6	Centrifugering(1)	_
	Drain Normal	On
	Program option changes allowed	On
	Extract Time (Min:Sec)	00:30 1015
2	Extract Speed in Rpm	1015
7	Sköljning(1)	On
	Reheat	
	Module heated	On
	Program option changes allowed	On 04:00
	Wash Time (Min:Sec)	0°C
	Temperature Temperature Hystereses	4°C
	Max Temp. Increase per min	38°C
	First Fill Level (Set mm)	61
	Second Fill Level (Set mm)	102
	Level Hystereses (Scale Units)	50
	Cold Water	On
	Motor action fill	2
	Motor action heat	2 2
	Hotor action wash	30
	Motor Speed During Filling (Rpm) Motor Speed During Heating (Rpm)	49
	Motor Speed During Wash (Rpm)	49
	Motor acceleration (RPM/sec) during filling	25 25
	Motor acceleration (RPM/sec) during filling Motor acceleration (RPM/sec) during heating	
	Motor acceleration (RPM/sec) during wash	25
8	Avlopp(2)	
	Drain Normal	On
	Motor Action	2
	Orain Time (min:sec)	00:10
	Distribution Time (min:sec)	00:01
	Motor Speed During Drain Time (Rpm)	49 25
_	Motor Acceleration During Drain (Rpm/sec)	23
9	Centrifugering(2)	On
	Drain Normal	On
	Program option changes allowed	00:30
	Extract Time (Min:Sec)	1015
	Extract Speed in Rpm	
10	Skölining(2)	On
	Reheat	On
	Module heated Program option changes allowed	On
	Wash Time (Min:Sec)	04:00
	Temperature	0°C
	Temperature Hystereses	4°C
	Max Temp. Increase per min	38°C
	First Fill Level (Set mm)	61
	Second Fill Level (Set mm)	102
	Level Hystereses (Scale Units)	50 On
	Cold Water	on 3
	Motor action fill	2 2
	Motor action heat Motor action wash	2
	Motor Speed During Filling (Rpm)	30
	Motor Speed During Heating (Rpm)	49



	PROGRAM I	
	Motor Speed During Wash (Rpm)	49
	Motor acceleration (RPM/sec) during filling	25
	Motor acceleration (RPM/sec) during heating	25
	Motor acceleration (RPM/sec) during wash	25
11	Avlopp(3)	
**	Drain Normal	On
	Motor Action	2
	Drain Time (min:sec)	00:10
	Distribution Time (min:sec)	00:01
	Motor Speed During Drain Time (Rpm)	49
	Motor Acceleration During Drain (Rpm/sec)	25
12	Centrifugering(3)	
	Drain Normal	On
		On
	Program option changes allowed	00:30
	Extract Time (Min:Sec)	1015
	Extract Speed in Rpm	1013
13	Sköljning(3)	Qn.
	Reheat	
	Module heated	On
	Program option changes allowed	On 04:00
	Wash Time (Min:Sec)	
	Temperature	0°C 4°C
	Temperature Hystereses	4°C 38°C
	Max Temp. Increase per min	61
	First Fill Level (Set mm)	102
	Second Fill Level (Set mm)	50
	Level Hystereses (Scale Units)	90
	Cold Water	On
	Hot water flush Notor action fill	2
	Motor action heat	2
	Motor action wash	2
	Motor Speed During Filling (Rpm)	30
	Motor Speed During Heating (Rpm)	49
	Motor Speed During Wash (Rpm)	49
	Motor acceleration (RPM/sec) during filling	25
	Motor acceleration (RPM/sec) during heating	25
	Motor acceleration (RPM/sec) during wash	25
	Detergent Compartment 3	Level no refill
	Detergent Signal 3	00:10
14	Aviopp(4)	
	Drain Normal	On
	Motor Action	2
	Drain Time (min:sec)	00:10
	Distribution Time (min:sec)	00:01
	Motor Speed During Drain Time (Rpm)	49
	Motor Acceleration During Drain (Rpm/sec)	25
15	Centrifugering(4)	
	Drain Normal	On
	Program option changes allowed	On
	Extract Time (Min:Sec)	05:10
	Extract time (min:sec) Extract Speed in Rpm	1245
46		
16	Slut	

2018-02-08	W575H	



Program 2 Ultra-pure)

PROGRAM 2

Free text	Hårt smutsat	
Machine Modules	W575H 22	
O Huvu	ddata	
Buzzer	at Program end	
Program	, flush valve from wash program n option changes allowed	č
Motor	ction 1 on time, CW	00:0
Motor	ction 1 on time, CCW	00:0
Motor a	ction 1 off time ction 2 on time, CW	00::
Motor	ction 2 on time, CCW	00:
	action 2 off time	00:0
	oction 3 on time, CCW	00:0
Motor	oction 3 off time	00:0
Motor	action 4 off time	00:0
	ätt(1)	
	heated	00:
Wash Tempe	ime (Min:Sec)	00:
	rature Hystereses	4
	mp. Increase per min	40
Second	ll Level (Set mm) I Fill Level (Set mm)	-
Level I	lystereses (Scale Units)	
Cold W	ater action fill	
Motor	action heat	
Motor	action wash Speed During Filling (Rpm)	
Motor	Speed During Heating (Rpm)	
	Speed During Wash (Rpm)	
	acceleration (RPM/sec) during filling acceleration (RPM/sec) during heating	
Motor	acceleration (RPM/sec) during wash	
2 Förty	ätt(2)	- 0
Wash	heated Time (Min:Sec)	00:
Tempe	rature	0
Tempe Max Tr	rature Hystereses emp. Increase per min	40
Level I	tystereses (Scale Units)	
Cold W	ater action fill	
	action heat	
Motor	action wash	
Motor	Speed During Filling (Rpm) Speed During Heating (Rpm)	
Motor	Speed During Wash (Rpm)	
Motor	acceleration (RPM/sec) during filling acceleration (RPM/sec) during heating	
Motor	acceleration (RPM/sec) during wash	
	/ätt(3)	
Modul	e heated Fime (Min:Sec)	02:
Tempe	rature	0
	erature Hystereses emp. Increase per min	40
	ill Level (Set mm)	
Secon	d Fill Level (Set mm)	
Cold V	Hystereses (Scale Units) Vater	
Motor	action fill	
	action heat action wash	
	Speed During Filling (Rpm)	
Motor	Speed During Heating (Rpm)	
Motor	Speed During Wash (Rpm) acceleration (RPM/sec) during filling	
Motor	acceleration (RPM/sec) during heating	
	acceleration (RPM/sec) during wash	
	vätt(4)	



	Module heated Wash Time (Min:Sec)	On 00:30
	Temperature	0°C 4°C
	Temperature Hystereses Max Temp. Increase per min	40°C
	Second Fill Level (Set mm)	73
	Level Hystereses (Scale Units)	21
	Cold Water	On 2
	Motor action fill Motor action heat	2 2 2
	Motor action wash	
	Motor Speed During Filling (Rpm)	30
	Motor Speed During Heating (Rpm) Motor Speed During Wash (Rpm)	49 49
	Motor acceleration (RPM/sec) during filling	25 25
	Motor acceleration (RPM/sec) during heating	25
-	Motor acceleration (RPM/sec) during wash	23
5	Avlopp(1) Drain Normal	On
	Motor Action	2
	Drain Time (min:sec)	00:10 00:01
	Distribution Time (min:sec)	49
	Motor Speed During Drain Time (Rpm) Motor Acceleration During Drain (Rpm/sec)	25
6	Huvudtvätt(1)	
•	Reheat	On
	Module heated	On
	Wash Time (Min:Sec)	00:30 0°C
	Temperature Temperature Hystereses	4°C
	Max Temp. Increase per min	38°C
	First Fill Level (Set mm)	25 25
	Second Fill Level (Set mm)	10
	Level Hystereses (Scale Units) Cold Water	On
	Motor Speed During Filling (Rpm)	30
	Motor Speed Duning Reading (Rpm)	49
	Motor Speed During Wash (Rpm) Motor acceleration (RPM/sec) during filling	49 25
	Motor acceleration (RPM/sec) during heating	25
	Motor acceleration (RPM/sec) during wash	25 00:20
7	Detergent Compartment 4 Huvudtvätt(2)	00:20
	Reheat	On
	Module heated	On 00:30
	Wash Time (Min:Sec)	0°C
	Temperature Temperature Hystereses	4°C
	Max Temp. Increase per min	38°C
	Level Hystereses (Scale Units)	10 2
	Motor action fill Motor action heat	2
	Motor action wash	2
	Motor Speed During Filling (Rpm)	30
	Motor Speed During Heating (Rpm)	49 49
	Motor Speed During Wash (Rpm) Motor acceleration (RPM/sec) during filling	25
	Motor acceleration (RPM/sec) during heating	25
	Motor acceleration (RPM/sec) during wash	25 00:10
	Detergent Compartment 4 Detergent Compartment 5	00:10
	Detergent Signal 2	00:10
8	Huvudtvätt(3)	
_	Wash Time (Min:Sec)	02:30
	Temperature	0°C 4°C
	Temperature Hystereses Max Temp. Increase per min	38°C
	First Fill Level (Set mm)	61
	Second Fill Level (Set mm)	70 10
	Level Hystereses (Scale Units)	2
	Motor action fill Motor action heat	2 2
	Motor action wash	2
	Motor Speed During Filling (Rpm)	30 49
	Motor Speed During Heating (Rpm)	49
	Motor Speed During Wash (Rpm) Motor acceleration (RPM/sec) during filling	25
	Motor acceleration (RPM/sec) during heating	25
	Motor acceleration (RPM/sec) during wash	25 Level refili
	Detergent Compartment 5	Level letti
9	Huvudtvätt(4)	

Electrolux

	Module heated Wash Time (Min:Sec)	00:30
	Temperature	0°0
	Temperature Hystereses	4°0
	Max Temp. Increase per min	38°C 73
	Second Fill Level (Set mm) Level Hystereses (Scale Units)	21
	Motor action fill	
	Motor action heat	
	Motor action wash	30
	Motor Speed During Filling (Rpm)	49
	Motor Speed During Heating (Rpm) Motor Speed During Wash (Rpm)	49
	Motor acceleration (RPM/sec) during filling	25
	Motor acceleration (RPM/sec) during heating	25
	Motor acceleration (RPM/sec) during wash	25 Level refil
40	Detergent Compartment 5	Level rem
10	Avlopp(2) Drain Normal	Or
	Motor Action	
	Drain Time (min:sec)	00:10
	Distribution Time (min:sec)	00:03
	Motor Speed During Drain Time (Rpm)	21
11	Motor Acceleration During Drain (Rpm/sec) Centrifugering(1)	-
**	Drain Normal	Or
	Program option changes allowed	Or
	Extract Time (Min:Sec)	00:30
	Extract Speed in Rpm	101
12	Sköljning(1)	
	Reheat	Or
	Module heated	Or
	Program option changes allowed Wash Time (Min:Sec)	04:00
	Temperature	0°0
	Temperature Hystereses	400
	Max Temp. Increase per min	38°0
	First Fill Level (Set mm)	6:
	Second Fill Level (Set mm) Level Hystereses (Scale Units)	50
	Cold Water	Or
	Motor action fill	
	Motor action heat	
	Motor action wash	30
	Motor Speed During Filling (Rpm) Motor Speed During Heating (Rpm)	4
	Motor Speed During Wash (Rpm)	49
	Motor acceleration (RPM/sec) during filling	2
	Motor acceleration (RPM/sec) during heating	2: 2:
13	Motor acceleration (RPM/sec) during wash	2
13	Aviopp(3) Drain Normal	O
	Motor Action	
	Drain Time (min:sec)	00:1
	Distribution Time (min:sec)	00:0
	Motor Speed During Drain Time (Rpm)	4
	Motor Acceleration During Drain (Rpm/sec)	
14	Centrifugering(2) Drain Normal	0
	Program option changes allowed	0
	Extract Time (Min:Sec)	00:3
	Extract Speed in Rpm	101
15	Skölining(2)	
	Reheat	O
	Module heated	0
	Program option changes allowed	04:0
	Wash Time (Min:Sec) Temperature	0°
	Temperature Hystereses	40
	Max Temp. Increase per min	38°
	First Fill Level (Set mm)	6
	Second Fill Level (Set mm)	10 5
	Level Hystereses (Scale Units)	Ö
	Cold Water Motor action fill	
	Motor action heat	
	Motor action wash	L.
	Motor Speed During Filling (Rpm)	3
	Motor Speed During Heating (Rpm) Motor Speed During Wash (Rpm)	

Electrolux

	Motor acceleration (RPM/sec) during filling	25 25
	Motor acceleration (RPM/sec) during heating	25
27210	Motor acceleration (RPM/sec) during wash	25
16	Avlopp(4)	
	Drain Normal	On 2
	Motor Action	00:10
	Drain Time (min:sec)	00:10
	Distribution Time (min:sec)	49
	Motor Speed During Drain Time (Rpm)	25
4.00	Motor Acceleration During Drain (Rpm/sec)	23
17	Centrifugering(3)	On
	Drain Normal	
	Program option changes allowed	On 00:30
	Extract Time (Min:Sec)	1015
	Extract Speed in Rpm	1015
18	Sköljning(3)	1.00
	Reheat	On
	Module heated	On
	Program option changes allowed	On
	Wash Time (Min:Sec)	04:00
	Temperature	0°C
	Temperature Hystereses	38°C
	Max Temp. Increase per min	61
	First Fill Level (Set mm)	102
	Second Fill Level (Set mm)	50
	Level Hystereses (Scale Units) Cold Water	00
	Hot water flush	Qn
	Motor action fill	2
	Motor action heat	2 2
	Motor action wash	2
	Motor Speed During Filling (Rom)	30
	Motor Speed During Heating (Rpm)	49
	Motor Speed During Wash (Rpm)	49
	Motor acceleration (RPM/sec) during filling	25 25
	Motor acceleration (RPM/sec) during heating	25 25
	Motor acceleration (RPM/sec) during wash	
	Detergent Compartment 3	Level no refill 00:10
	Detergent Signal 3	00:10
19	Avlopp(5)	
	Drain Normal	On
	Motor Action	00:10
	Drain Time (min:sec)	00:01
	Distribution Time (min:sec) Motor Speed During Drain Time (Rpm)	49
	Motor Acceleration During Drain (Rpm/sec)	25
20	Centrifugering(4)	-
20	Drain Normal	On
		On
	Program option changes allowed	05:10
	Extract Time (Min:Sec)	1245
-	Extract Speed in Rpm	1243
21	Slut	

2018-02-09 W575H

Program Normal 60 Colour

lux Laundry Systems

1(1)

418776123 6A01 SE CH EL/DS W575H 1E 2F

NORMAL 60 COLOUR - (A01)

Module	Param		Hot Flush	Valves	Pump	1st Lvi	2nd Lvl	Lvi Hyst	Temp	Time (s)	Fit	Heat	Wash	RPM
Weight										90 s				
Mainwash				C	2	40	40	10	O°C	30 s	2	2	2	
Fump time					10									
Mainwash				н		61	70	10	50°C	150 s	2	2	2	
Mainwash	3			н			68	21	52°C	60 s	2	2	2	
Mainwash	Y	Y		н			6.9	21	52°C	1020 s	2	2	2	
Drain	Y	Y								30 s			2	
Extract	Y	Y								60 s				1015
Rinse	Y	Y		С		61	75	50	0°C	240 s	2	2	2	
Drain	Ý	Y								30 s			2	
Extract	Ý	Y								60 s				1015
Rinse	Ý	Y		C	3	61	75	50	0°C	240 s	2	2	2	
Pump time	_	<u> </u>			10	-								
Drain	Y	Y								30 s			2	
Extract	Y	Ý								360 s				1245

NOTE: Column Valves in table indicates "Powder detergent valves", whilst the column Aump indicates "Liquid detergent". When "C" or "H" is present in column Aump indicates "Liquid detergent". When "C" or "H" is present in column Aump indicates "Liquid detergent". When "C" or "H" is present in

FIII/Heat/Wash on/of Motor action 1 6/18 Motor action 2 15/4 Motor action 3 8/7 Motor action 4 0/3

Value	Flow	Temperature	Separate valve
Powder detergent valve 1	20 Vmin	Cold	No
Powder detergent valve 2	20 Vmin	Cold	No
Powder detergent valve 3	5 l/min	Cold	No
Powder detergent valve 4	20 l/min	Hot	No
Powder detergent valve 5	20 l/min	Hot	No
Powder detergent valve 6	20 Vmin	Cold	No
	2011-1-	Cold	No

418776123 8.24.g7s

2017-03-20 13:20:24

